

FIG. 1




FIG. 2

114
RELEASE SWITCH
118
ZOOM SWITCH
116
FUNCTION
SETTING
SECTION
119
DATA
SELECTION
SWITCH

COMMON OPERATION MEMBER	AUDIO OPERATION MODE	CAMERA OPERATION MODE
RELEASE SWITCH	PLAY/STOP/PAUSE	SHUTTER OPERATION
ZOOM SWITCH	VOLUME CONTROL (MAX → MIN)	ZOOM OPERATION (WIDE → TELE)
DATA SELECTION SWITCH	FORWARD/BACK OF NUMBERS	SINGLE FRAME STEP FUNCTION OF PLAYING IMAGES

FIG. 3




FIG. 4


10

FIG. 5




FIG. 6


10

FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11




FIG. 12